



1. Artificial horizon
2. Visual homing indicator
3. Turn and bank indicator
4. Blind approach indicator
5. Variometer
6. Airspeed indicator
7. Altimeter
8. Repeater compass
9. Directional gyro
10. Left engine tachometer
11. Right Engine tachometer
12. Left engine oil temperature gauge
13. Right engine oil temperature gauge
14. Left engine fuel and oil pressure gauge
15. Left engine manifold pressure gauge
16. Right engine manifold pressure gauge
17. Left engine cooling liquid temperature gauge
18. Right engine cooling liquid temperature gauge
19. Right engine fuel and oil pressure gauge
20. Clock
21. Left side propeller pitch indicator
22. Right side propeller pitch indicator
23. Flaps position indicator
24. Gear position indicator:  green - down  
 red - up
25. Left engine throttle
26. Right engine throttle
27. Left engine supercharger lever:  rear pos. - stage 1  
 front pos. - stage 2
28. Right engine supercharger lev.:  rear pos. - stage 1  
 front pos. - stage 2
29. Left side propeller pitch lever
30. Right side propeller pitch lever
31. Flaps lever
32. Left engine mixture lever:  rear pos. - leaner mixt.  
 front pos. - richer mixt.
33. Right engine mixture lever:  rear pos. - leaner mixt.  
 front pos. - richer mixt.
34. Left engine oil radiator lever:  rear pos. - closed  
 front pos. - open
35. Right engine oil radiator lever:  rear pos. - closed  
 front pos. - open

36. Low fuel warning light
37. Left wing tank fuel gauge
38. Right wing tank fuel gauge
39. Low fuel warning light
40. Left engine fuel and oil pressure gauge
41. External air temperature gauge
42. Right engine fuel and oil pressure gauge

