

Messerschmitt Bf109Z «Zwilling»



1. Ammunition counter - left cannon
2. Ammunition counter - optional MK103 gunpod
3. Ammunition counter - right cannon
4. Clock
5. Left engine magnetos position
6. Right engine magnetos position
7. Repeater compass
8. Artificial horizon / turn and bank indicator
9. Left engine manifold pressure gauge (white needle) and tachometer (yellow needle)
10. Right engine manifold pressure gauge (white needle) and tachometer (yellow needle)
11. Undercarriage position indicator: green - down
no light - transition
red - up
12. Altimeter
13. Airspeed indicator
14. Left engine coolant temperature gauge
15. Right engine coolant temperature gauge
16. Left engine fuel and oil pressure indicator
17. Right engine fuel and oil pressure indicator
18. Low fuel warning light
19. Propeler pitch indicator for left and right engine
20. Fuel gauge
21. Left engine throttle
22. Right engine throttle

